

Misting Rehab Shower RH7000

Shower Assembly

- A. Insert Base Extenders (#1) into Base Upright (#2)
- B. Insert Top Upright (#3) into Base Upright (#2)
- C. Attach hose.
- D. Turn on water (heads work with water pressures 30-70 psi)

Important

To prevent clogging of the small orifices in the misting heads, a hose strainer is installed in the hose coupling. It should be in place whenever the Misting Shower is in use. Clean regularly by gently removing and rinsing. In the unlikely event that the misting heads become clogged, they can be removed from the pipe by gently turning counterclockwise with a 9/16" wrench. Remove inner piece with screwdriver and flush with a stream of water or compressed air. Reassemble gently being careful not to cross thread in PVC pipe. Tighten snugly but do not over tighten.

Parts List Replacement parts are available, contact DQE to order.

PART NAME	QTY	PART NUMBER
1. Base Extenders	4	RHPT7000-1
2. Base Upright	1	RHPT7000-2
3. Top Upright	1	RHPT7000-3
4. Mesh Bag	1	HMPTRH7000-2

