

PSI	GPM
4	766
5	856
6	938
7	1013
8	1083
9	1149
10	1211
PSI 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28	GPM 766 856 938 1013 1083 1149 1211 1247 1303 1356 1407 1456 1504 1550 1595 1639 1682 1723 1764 1803 1842 1880 1917 1954 1990
12	1303
13	1356
14	1407
15	1456
16	1504
17	1550
18	1595
19	1639
20	1682
21	1723
22	1764
23	1803
24	1842
25	1880
26	1917
27	1954
28	1990

PSI	GPM
29	2025
30	2059
31	2093
32	2127
33	2160
34	2192
35	2224
36	2256
37	2263
38	2293
39	2323
40	2353
41	2382
42	2059 2093 2127 2160 2192 2224 2256 2263 2293 2353 2353 2382 2411 2439 2468 2495 2523 2550 2577
43	2439
44	2468
45	2495
46	<b>2523</b>
47	2550
48	2577
49	2604
29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53	2630
51	2657
52	2683
53	2604 2630 2657 2683 2708

## The readings on this chart are based on pitot diameter orifice.

It is the user's responsibility to verify that the correct chart and column is being used.

This device is FM Approved. The data included in this chart has been examined and confirmed for accuracy. Please call us or instruct the Authority Having Jurisdiction to call us if there are any questions. Additional copies of flow charts are available at: www.hosemonster.com





MANUFACTURED BY:
The Hose Monster Company
(888) 202-9987 Toll Free
(847) 434-0073 Fax
Service@FlowTest.com
www.HoseMonster.com