


**PLASTIC AIR CYLINDER AND EXTINGUISHER CRADLES  
 MODELS QS-PC-VS & QS-PC-TDS  
 PARTS AND INFORMATION MANUAL**



Mount using 1/4" hardware

MODEL	DESCRIPTION	WT./@ IN LBS.
QS-PC-VS	Cradle with Valve Strap	1.15
QS-PC-TDS	Cradle with Tie-Down Strap	1.15

Replacement Strap Part Numbers:

Valve Strap: 1090-255-120

Tie Down Strap: 1010-110-105



*Ziamatic Corp.*

10 West College Avenue, P.O. Box 337, Yardley, PA 19067-0587 • (215) 493-3618 • FAX: (215) 493-1401

www.ziamatic.com

TOLL FREE: 800-711-3473