IMPORTANT INFORMATION - PLEASE READ AND SAVE



LEVR[™] Escape System Made in USA

of US and foreign components

- SERIOUS INJURY OR DEATH MAY RESULT FROM THE IMPROPER USE OF THIS EQUIPMENT.
- THIS EQUIPMENT HAS BEEN DESIGNED AND MANUFACTURED FOR USE BY EXPERIENCED PROFESSIONALS ONLY.
- DO NOT ATTEMPT TO USE THIS EQUIPMENT WITHOUT PRIOR TRAINING.
- THOROUGHLY READ AND UNDERSTAND ALL LABELS AND INSTRUCTIONS BEFORE USE.
- USE, INSPECT AND REPAIR ONLY IN ACCORDANCE WITH MANUFACTURER'S INSTRUCTIONS.



MEETS THE FIRE ESCAPE SYSTEM REQUIREMENTS OF NFPA 1983, STANDARD ON LIFE SAFETY ROPE AND EQUIPMENT FOR EMERGENCY SERVICES, 2017 EDITION. DOT NOT DISASSEMBLE.

> EMERGENCY SERVICES FIRE ESCAPE SYSTEM IN ACCORDANCE WITH NFPA 1983 – 2017.

CMC Rescue, Inc.

6740 Cortona Drive, Goleta CA 93117 USA 805-562-9120 / 800-235-5741 **cmcpro.com**

ISO 9001 Certified

©2018 CMC Control No. 500360.00.042318

USER INFORMATION

User Information shall be provided to the user of the product. NFPA Standard 1983 recommends separating the User Information from the equipment and retaining the information in a permanent record. The standard also recommends making a copy of the User Information to keep with the equipment and that the information should be referred to before and after each use.

Additional information regarding life safety equipment can be found in NFPA 1858, Standard on Selection Care, and Maintenance of Life safety Rope and Equipment for Emergency Services, NFPA 1500, Standard on Fire Department Occupational Safety and Health Programs, and NFPA 1983, Standard on Life Safety Rope and Equipment for Emergency Services.

INSPECTION

Inspect the equipment according to your department's policy for inspecting life safety equipment. Inspect the equipment prior to entry into service, after each use, and at least once every 12 months. The equipment should be thoroughly inspected by an inspector that meets your department's training standard for inspection of life safety equipment. Keep a record of the date, person performing the inspection and results, as well as the date of first use, name of users and any other pertinent information necessary to keep accurate track of the equipment's usage history in the equipment log or on a tag that attaches to the equipment. Each user should be trained in equipment inspection and should inspect the equipment before each use.

When inspecting the system, follow the manufacturer's recommendations for inspection provided with each of the LEVR Escape System components. If the system is used in actual fire ground emergency escape, or if there is any doubt about the serviceability of the system, remove the system from service and destroy it.

The service life of equipment depends greatly on the type of use and the environment of use. Because these factors vary greatly, a precise service life of the equipment cannot be provided.

CERTIFICATION

The LEVR[™] (300953), ProTech[™] Carabiner (300153), FlashLite[™] Hook Escape Anchor (300981) and Fire Escape Web (200517) are individually certified to NFPA 1983. The LEVR Escape System is an NFPA 1983 certified Manufactured Fire Escape System when used with the following components:

- CMC LEVR (300953)
- CMC FlashLite Hook Escape Anchor (300981)
- CMC Fire Escape Web (292015) with CMC factory sewn termination

USING THE ESCAPE SYSTEM

For proper deployment of the LEVR Escape System, refer to the included User Information for the LEVR, FlashLite Hook Escape Anchor, ProTech Carabiner and Fire Escape Web.

When repacking the system into the supplied CMC carry bag, stuff the web into the main pouch to minimize twisting during deployment. Also make sure that the FlashLite Hook and the LEVR are properly stowed in their respective holders and will deploy freely.

If storing the LEVR Escape System directly in the bunker pants pocket or using a different external bag than the supplied CMC carry bag ensure that the web is properly stuffed and the hardware is packed such that it will deploy freely.

To view a video with more information and detailed instructions on properly packing the LEVR Escape System, please visit **cmcpro.com**

CARRYING, MAINTENANCE & STORAGE

During use, carrying and storage keep the equipment away from acids, alkalis, exhaust emissions, rust and strong chemicals. Do not expose the equipment to flame or high temperatures. Carry the equipment where it will be protected as the equipment could melt or burn and fail if exposed to flame or high temperatures.

If the equipment becomes soiled, it can be washed in cold water with a mild detergent that is safe for use with nylon and polyester. Dry out of direct sunlight. Do not dry in an automatic dryer. Store in a cool, dry location. Do not store where the equipment may be exposed to moist air, particularly where dissimilar metals are stored together.

FR ESCAPE WEB REPLACEMENT

The LEVR is pre-rigged with approved FR Escape Web prior to shipping from CMC. If web replacement is necessary, contact CMC Customer Support (800-235-5741) to initiate the RMA process. In addition to replacing the web, the components of the escape system will be inspected by the manufacturer.

REPAIR

All repair work shall be performed by the manufacturer. All other work or modifications void the warranty and releases CMC from all liability and responsibility as the manufacturer.

SAMPLE INSPECTION AND MAINTENANCE LOG

The sample log suggests records that should be maintained by the purchaser or user of life safety equipment.

Equipment Inspection and Maintenance Log			
Item	#	Date in Service	
Brand/Mod	el	Strength	
Date	How Used or Maintained	Comments	Name

